













Betriebsanleitung  
 Operating Instructions  
 Instructions de service  
 Istruzioni d'uso  
 Handleiding  
 Instrucciones para el manejo  
 Manual de instruções  
 Naudojimosi instrukcija  
 Kasutusjuhend  
 Lietošanas instrukcija  
 Driftsinstruks  
 Driftsinstruktioner  
 Käyttöohje  
 Driftsvejledning  
 Instrukcja obsługi


Kezelési útmutató  
 Návod k obsluze  
 Navodilo za uporabo  
 Návod na obsluhu  
 Upute za rad  
 Manual de operatii  
 Treoracha Oibriúcháin  
 Οδηγίες χρήσης  
 El Kitabi  
 Инструкции за експлоатация  
 Инструкция по эксплуатации  
 取扱説明書  
 사용설명서  
 使用说明书

			<p><b>MAX. PRESSURE</b></p>		<p>mbar</p>
				<p><b>MAX.</b></p>	
<p><b>AIR</b></p>			<p>DIN EN ISO 2151</p> <p>DIN EN ISO 3744</p>	<p><math>L_{pA} = 60 \text{ dB(A)} - 50\text{Hz}</math></p> <p><math>L_{pA} = 62 \text{ dB(A)} - 60\text{Hz}</math></p> <p><math>K_{pA} = 3 \text{ dB(A)}</math></p>	

				<p><math>A &gt; 100\text{mm}</math></p> <p><math>A &gt; 4"</math></p>	<p><math>&gt; 5^\circ\text{C}/41^\circ\text{F}</math></p> <p><math>&lt; 45^\circ\text{C}/113^\circ\text{F}</math></p>	<p>max. 90%</p>	<p>max. 800m</p>
<p>1</p> <p>16 kg 35,3 lbs</p>	<p>2</p>						








**F1:** D: 38 mm  
H: 38 mm  
No.: 90951801000



EN149 - FFP3  
42 CFR 84 - N100

**F2:** D: 38 mm  
H: 38 mm  
No.: 90955400000



**E.**



**F.**



7500 h




$A_{MAX} = 26\text{mm}$   
 $A_{MIN} = 18\text{mm}$

$A_{\text{err}} < 18\text{mm}$  →





→ No. 90139800007 (SET)

**G.**



**H.**



[www.becker-international.com](http://www.becker-international.com)



Gebr. Becker GmbH  
Hölker Feld 29-31  
D-42279 Wuppertal  
[info@becker-international.com](mailto:info@becker-international.com)



**SERVICE**

[www.becker-international.com](http://www.becker-international.com)

Sales and service network