


BETRIEBSANLEITUNG
OPERATING INSTRUCTIONS
INSTRUCTIONS DE SERVICE
ISTRUZIONI D'USO
HANDLEIDING
INSTRUCCIONES PARA EL MANEJO
MANUAL DE INSTRUÇÕES
NAUDOJIMOSI INSTRUKCIJA
KASUTUSJUHEND
LIETOŠANAS INSTRUKCIJA
DRIFTSINSTRUKS
DRIFTSINSTRUKTIONER
DRIFTSVEJLEDNING
INSTRUKCJA OBSŁUGI

KEZELÉSI ÚTMUTATÓ
NÁVOD K OBSLUZE
NAVODILO ZA UPORABO
NÁVOD NA OBSLUHU
UPUTE ZA RAD
MANUAL DE OPERATII
TREORACHA OIBRIÚCHÁIN
ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ
EL KITABI
ИНСТРУКЦИИ ЗА ЕКСПЛОАТАЦИЯ
ИНСТРУКЦИЯ ПО ЕКСПЛУАТАЦИИ
取扱説明書
사용설명서
使用说明书

KDX 3.80

MAKE IT BECKER.








1

MAX. PRESSURE



mbar

MAX. V





m³/h


L_{pA}

DIN EN ISO 11203
Accuracy Class 2
K_{PA} = 3 dB(A)
l ← 1m

L_{pA} = 74 dB(A) - 50Hz
L_{pA} = 76 dB(A) - 60Hz

2







3


A > 100mm
A > 4"






4





5



6

MOTOR-PROTECTION
=

50Hz		60Hz	
XXX / XXX V	XXX / XXX V	XXX / XXX V	XXX / XXX V
XXX / XXX A	XXX / XXX A	XXX / XXX A	XXX / XXX A

SERVICE FACTOR
X
RATED CURRENT

7

optional

Bi-metal

PTC

1) motor protection switch

8

9

10

PRESSURE



11

BECKER

year: XXX/20XX
No.: A1234567
Compressor / vacuum pump
type: XXX Hz
frequency: XXX rpm⁻¹
speed: XXX kW
power required: XXX m³/h
inlet capacity: XXX m³/h
pressure: XXX mbar
vacuum: XXX mbar


12

Maintenance




13



14




CLEANING
INTERVAL



15




16




F1
No.: 90950701


17




18




19




20




21



22




23




24



7500 h




$A_{MAX} = 38mm$
 $A_{MIN} = 26mm$
 $A_{TIT} < 26mm$ → 



→ No. 90140100004 (SET)


25




26




Special grease
No.96000002300




27




28



29



30



WWW.BECKER-INTERNATIONAL-SHOP.COM

Gebr. Becker GmbH
 Hoelker Feld 29-31
 42279 WUPPERTAL
 GERMANY
info@becker-international.com
www.becker-international.com





MAKE IT BECKER.